



This product is designed for advanced vapers, for o nicotine juices. You must understand Ohm's Laws and your own device's limits. Use only with High drain Cells, in parallel when required. Mount the coils without touching the deck or the cap, staying as closer to the post as possible.

Pre-fire ohm reading may be very low due to eventual hotspots, they must be removed before wicking;
Hotspot fixing must be done at half the power of vaping, and can be done by gently touch and move the wraps where you see them.
If you must use a mechanical devices for hotspot fixing, proceed with rapid short activation to identify the hotspot and remove them.
When the coils lights up uniformly, from inside to the outside you can wick the coil. It's important to wick VERY hard these coils, aiming to an high density wicking inside the coil. but keeping the bottom of the

an high density wicking inside the coil, but keeping the bottom of the coil free to breathe. It's important to dryburn your coil when they get too dirty; If possible, wash and gently brush the coils before, the dryburning must be done at half the power of vaping.